

Federal Communications Commission

§ 11.20

(1) A “wireless cable system” is a collection of channels in the BRS or EBS used to provide video programming services to subscribers. The channels may be licensed to or leased by the wireless cable system operator.

(2) A “wireless cable operator” is the entity that has acquired the right to use the channels of a wireless cable system for transmission of programming to subscribers.

(d) Local franchise authorities may use any EAS codes authorized by the FCC in any agreements.

(e) Other technologies and public service providers, such as low earth orbiting satellites, that wish to participate in the EAS may contact the FCC’s Public Safety and Homeland Security Bureau or their State Emergency Communications Committee for information and guidance.

[63 FR 29662, June 1, 1998, as amended at 65 FR 7639, Feb. 15, 2000; 65 FR 21657, Apr. 24, 2000; 65 FR 30001, May 10, 2000; 65 FR 34406, May 30, 2000; 67 FR 18506, Apr. 16, 2002; 69 FR 72031, Dec. 10, 2004; 70 FR 19315, Apr. 13, 2005; 70 FR 71031, Nov. 25, 2005; 71 FR 76220, Dec. 20, 2006; 72 FR 62132, Nov. 2, 2007; 77 FR 16699, Mar. 22, 2012]

§§ 11.12–11.14 [Reserved]

§ 11.15 EAS Operating Handbook.

The EAS Operating Handbook states in summary form the actions to be taken by personnel at EAS Participant facilities upon receipt of an EAN, an EAT, tests, or State and Local Area alerts. It is issued by the FCC and contains instructions for the above situations. A copy of the Handbook must be located at normal duty positions or EAS equipment locations when an operator is required to be on duty and be immediately available to staff responsible for authenticating messages and initiating actions.

[70 FR 71033, Nov. 25, 2005]

§ 11.16 National Control Point Procedures.

The National Control Point Procedures are written instructions issued by the FCC to national level EAS control points. The procedures are divided into sections as follows:

(a) *National Level EAS Activation*. This section contains the activation and

termination instructions for Presidential messages.

(b) *EAS Test Transmissions*. This section contains the instructions for testing the EAS at the National level.

(c) *National Information Center (NIC)*. This section contains instructions for distributing United States Government official information messages after completion of the National Level EAS activation and termination actions.

[59 FR 67092, Dec. 28, 1994, as amended at 67 FR 18508, Apr. 16, 2002]

§ 11.18 EAS Designations.

(a) National Primary (NP) is a source of EAS Presidential messages.

(b) Local Primary (LP) is a source of EAS Local Area messages. An LP source is responsible for coordinating the carriage of common emergency messages from sources such as the National Weather Service or local emergency management offices as specified in its EAS Local Area Plan. If it is unable to carry out this function, other LP sources in the Local Area may be assigned the responsibility as indicated in State and Local Area Plans. LP sources are assigned numbers (LP-1, 2, 3, etc.) in the sequence they are to be monitored by other broadcast stations in the Local Area.

(c) State Primary (SP) is a source of EAS State messages. These messages can originate from the Governor or a designated representative in the State Emergency Operating Center (EOC) or State Capital. Messages are sent via the State Relay Network.

(d) State Relay (SR) is a source of EAS State messages. It is part of the State Relay Network and relays National and State common emergency messages into Local Areas.

(e) Participating National (PN) sources transmit EAS National, State or Local Area messages. The EAS transmissions of PN sources are intended for direct public reception.

[59 FR 67092, Dec. 28, 1994, as amended at 77 FR 16700, Mar. 22, 2012]

§ 11.20 State Relay Network.

This network is composed of State Relay (SR) sources, leased common carrier communications facilities or

§ 11.21

any other available communication facilities. The network distributes State EAS messages originated by the Governor or designated official. In addition to EAS monitoring, satellites, microwave, FM subcarrier or any other communications technology may be used to distribute State emergency messages.

§ 11.21 State and Local Area plans and FCC Mapbook.

EAS plans contain guidelines which must be followed by EAS Participants' personnel, emergency officials, and National Weather Service (NWS) personnel to activate the EAS. The plans include the EAS header codes and messages that will be transmitted by key EAS sources (NP, LP, SP and SR). State and local plans contain unique methods of EAS message distribution such as the use of the Radio Broadcast Data System (RBDS). The plans must be reviewed and approved by the Chief, Public Safety and Homeland Security Bureau, prior to implementation to ensure that they are consistent with national plans, FCC regulations, and EAS operation.

(a) The State EAS Plan contains procedures for State emergency management and other State officials, the NWS, and EAS Participants' personnel to transmit emergency information to the public during a State emergency using the EAS. State EAS Plans should include a data table, in computer readable form, clearly showing monitoring assignments and the specific primary and backup path for emergency action notification (EAN) messages that are formatted in the EAS Protocol (specified in § 11.31), from the PEP to each station in the plan. If a state's emergency alert system is capable of initiating EAS messages formatted in the Common Alerting Protocol (CAP), its State EAS Plan must include specific and detailed information describing how such messages will be aggregated and distributed to EAS Participants within the state, including the monitoring requirements associated with distributing such messages.

(b) The Local Area plan contains procedures for local officials or the NWS to transmit emergency information to the public during a local emergency

47 CFR Ch. I (10–1–13 Edition)

using the EAS. Local plans may be a part of the State plan. A Local Area is a geographical area of contiguous communities or counties that may include more than one state.

(c) The FCC Mapbook is based on the above plans. It organizes all broadcast stations and cable systems according to their State, EAS Local Area, and EAS designation.

[72 FR 62134, Nov. 2, 2007, as amended at 77 FR 16700, Mar. 22, 2012]

Subpart B—Equipment Requirements

§ 11.31 EAS protocol.

(a) The EAS uses a four part message for an emergency activation of the EAS. The four parts are: Preamble and EAS Header Codes; audio Attention Signal; message; and, Preamble and EAS End Of Message (EOM) Codes.

(1) The Preamble and EAS Codes must use Audio Frequency Shift Keying at a rate of 520.83 bits per second to transmit the codes. Mark frequency is 2083.3 Hz and space frequency is 1562.5 Hz. Mark and space time must be 1.92 milliseconds. Characters are ASCII seven bit characters as defined in ANSI X3.4-1977 ending with an eighth null bit (either 0 or 1) to constitute a full eight-bit byte.

(2) The Attention Signal must be made up of the fundamental frequencies of 853 and 960 Hz. The two tones must be transmitted simultaneously. The Attention Signal must be transmitted after the EAS header codes.

(3) The message may be audio, video or text.

(b) The ASCII dash and plus symbols are required and may not be used for any other purpose. Unused characters must be ASCII space characters. FM or TV call signs must use a slash ASCII character number 47 (/) in lieu of a dash.

(c) The EAS protocol, including any codes, must not be amended, extended or abridged without FCC authorization. The EAS protocol and message format are specified in the following representation.

Examples are provided in FCC Public Notices.