

CCR-100 User Guide

2-19-15

1. Place puck firmly in arm-rest cup-holder, or if equipped with a clamp, clamp unit to the armrest.
2. Adjust arm so that unit is directly in front of, but slightly below your line of sight to the movie screen.
3. On the right side, switch the unit to RUN.
4. If necessary, press the language button multiple times to get to the appropriate available language.
5. Readjust the position and angle of the unit so that captions are clearly readable, slightly below your line of sight of the movie screen.
6. Enjoy the closed captions and your movie!

